







How to change spark plugs on Mercedes W202 – replacement guide



VIDEO TUTORIAL

① Important!

This replacement procedure can be used for: MERCEDES-BENZ C-CLASS (W202) C 220 (202.022)

The steps may slightly vary depending on the car design.

WWW.AUTODOC.CO.UK 1–23



REPLACEMENT: SPARK PLUGS – MERCEDES W202. LIST OF THE TOOLS YOU'LL NEED:



- High-temperature anti-seize lubricant
- Spark plug socket # 16
- HEX bit no.H5.
- Ratchet wrench

- Torque wrench
 - Flat Screwdriver
 - Fender cover

WWW.AUTODOC.CO.UK 2–23



Replacement: spark plugs – Mercedes W202. Tip from AUTODOC:

- The replacement procedure is the same for all spark plugs.
- All work should be done with the engine stopped.

REPLACEMENT: SPARK PLUGS – MERCEDES W202. RECOMMENDED SEQUENCE OF STEPS:

1



Open the hood.

WWW.AUTODOC.CO.UK 3–23





Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.


3



Detach the air intake hose clamp. Use a flat screwdriver.

WWW.AUTODOC.CO.UK 4–23





Unplug the mass air flow sensor connector.

5



Disconnect the air intake pipe from the air filter housing.

WWW.AUTODOC.CO.UK 5–23





Unscrew the clamp that fastens the air filter hose to the throttle body. Use a flat screwdriver.


7



Detach the vacuum pipe. Use a flat screwdriver.

WWW.AUTODOC.CO.UK 6–23





Dismantle the air filter pipe.

9



Unscrew the engine cover fastener. Use HEX No.H5. Use a ratchet wrench.

WWW.AUTODOC.CO.UK 7–23





Remove the engine cover. Use a flat screwdriver.

AUTODOC recommends:

 Replacement: spark plugs – Mercedes W202. To avoid damaging the part when removing it, do not use excessive force.

11



Remove the spark plug wire connectors from the spark plug wells.

WWW.AUTODOC.CO.UK 8–23



Replacement: spark plugs – Mercedes W202. Professionals recommend:

- Be careful to avoid damaging spark plug wires.
- Remember the sequence of the spark plug wires connectors.

12

Clean dirt, dust and debris from inside the spark plug wells.

13



Unscrew the spark plugs. Use the spark plug socket #16. Use a ratchet wrench.

WWW.AUTODOC.CO.UK 9–23





Take out the spark plugs. Use the spark plug socket #16.

15



Apply a thin layer of a special high temperature anti-seize lubricant to the threads of the new spark plugs.

WWW.AUTODOC.CO.UK 10–23





Install the new spark plugs into their mounting seats. Use the spark plug socket #16.

1/



Screw new spark plugs and tighten them. Use the spark plug socket #16. Use a torque wrench. Tighten it to 27 nm torque.

WWW.AUTODOC.CO.UK 11–23



Replacement: spark plugs – Mercedes W202. AUTODOC experts recommend:

- Don't tighten the plugs with excessive force. Exceeding tightening torque can damage the thread connection.
- Be careful when working with a spark plug wrench. Its skewing can cause damage to the threaded connection.

18




Install the spark plug wire connectors into the spark plug wells. Make sure you hear a click indicating that it is locked in place.

AUTODOC recommends:

 Replacement: spark plugs – Mercedes W202. Follow the installation steps.

WWW.AUTODOC.CO.UK 12–23





Install the engine cover and secure it.

Replacement: spark plugs – Mercedes W202. AUTODOC recommends:

- Make sure the engine cover is properly seated. It should not be displaced with respect to the guiding fasteners.
- Do not apply excessive force when installing the part. Otherwise you may damage the fasteners.

WWW.AUTODOC.CO.UK 13–23





Screw in the engine cover fasteners. Use HEX No.H5. Use a ratchet wrench.

21



Install the air filter pipe.

WWW.AUTODOC.CO.UK 14–23





Connect the air intake pipe to the air filter housing.

23



Fasten the clamp on the air intake hose. Use a flat screwdriver.

WWW.AUTODOC.CO.UK 15–23





Plug in the mass air flow sensor conntector.

25



Attach the vacuum pipe.

WWW.AUTODOC.CO.UK 16–23





Screw in the clamp that connects the air filter hose to the throttle body. Use a flat screwdriver.

27


Remove the fender protection cover.

28



Close the hood.

WWW.AUTODOC.CO.UK 17–23



Run the engine for a few minutes. This is necessary in order to make sure that the component operates properly.

30

Shut off the engine.

WWW.AUTODOC.CO.UK 18-23



DID YOU FIND THESE INSTRUCTIONS HELPFUL?

YES

NO




BECOME A MEMBER OF AUTODOC CLUB!

WWW.AUTODOC.CO.UK 19–23



AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE






WWW.AUTODOC.CO.UK 20–23







WWW.AUTODOC.CO.UK 21–23







WWW.AUTODOC.CO.UK 22–23





(i) Disclaimer:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AutoDoc shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AutoDoc shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists

AutoDoc shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AutoDoc strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2018 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by Autodoc GmbH.

WWW.AUTODOC.CO.UK 23–23